

Installation Guide for septic and holding tanks

All septic and holding tanks are BNQ & CSA approved

Important

- Tanks shall never be installed in clay and or water saturated clay
- Septic or holding tanks shall never be installed where water table is in contact with the base of the tank.
- Septic tanks shall be filled with water after each pump out, in order to prevent the collapsing of the tank. Septic tank only.
- Never use a septic tank as a holding tank or as a pumping station.
- Remove the 2 X 20" lids when pumping out. This will avoid air lock.
- Do not install Septic tank or drainage field across the path of vehicles or heavy equipment.
- Never use the septic tank or septic holding for potable water.

Warranty

Xactics™ septic tanks or holding tanks are guaranteed free of any manufacturing defect. This guarantee is limited to the original installation and is valid for a period of five (5) years from the date of manufacturing.

Our obligation with regards to this guarantee is limited to replacing a defective tank with another *Xactics™* tank after a manufacturing defect is proved and the conditions of the guarantee have been met, and does not include the costs of the removal of the defective tank or the costs of the installation and transportation of the replacement tank. (Please refer to our website www.xactics.com for more details)